

**4-BUTTON WIRELESS REMOTE CONTROL FOR GARAGE DOOR  
KT01-4**



### Specifications:

- Working Voltage: DC 12V (27A battery included)
- Operating Current:  $\leq 8\text{mA}$
- Working Frequency: 433.92 MHz (Optional: 315 MHz)
- Modulation Mode: ASK (AM)
- Transmission Power:  $\leq 100\text{mW}$
- Emission Distance: 50 to 100 meters (tested)
- Encoding Type: Self-encoded

### Programming instructions

Important notice: Please ensure the operating frequency of the copied remote control matches, or opt for a frequency-adjustable remote control. Before purchasing, verify if your remote control is copyable. It cannot copy original car remote controls, two-way remote controls, and rolling code remote controls. Rolling code chips typically start with HCS, such as HCS200, HCS201, HCS300, HCS301, etc.

### Code clear

1. Hold down buttons A and B until the LED indicator flashes.
2. Release button B while keeping button A pressed.
3. Press button B three times, ensuring button A remains pressed throughout.



## Code clone

1. Place the original remote and the clone remote close together. The distance should be 10mm or less.
2. Press and hold the button to be programmed on both remotes.
3. Hold until the LED on the clone remote flashes steadily. The blue LED will flash quickly three times, pause, then flash steadily for successful programming.
4. Programming is complete. Repeat these steps to program additional buttons



## Code Recovery

1. Hold down buttons C and D until the LED indicator flashes.
2. The code will revert to the last code you cloned.